



Solar Metrology


Metrology solutions for the complete value chain of solar cell and module production






In the next minutes you will:

- Get an introduction of the company Op-tection GmbH
- Get introduced to a selection of the metrology systems we built
- Discover the capabilities these systems provide you




Op-tection GmbH...






Op-tection GmbH...


- was founded in 2005
- is located in Heinsberg, Germany
- **is specialized in optics, spectroscopy and image processing**
- benefits from a strong background in high-tech industries
- **successfully established its metrology solutions for the PV industry**
- helps its customers to create competitive advantages using advanced QC solutions



Present around the globe

- Headquarters in Germany
- North America
- South America
- China
- Taiwan
- Singapore
- Vietnam
- South Korea
- United Arab Emirates






Install Base



• Installation Sites

Isn't it a great feeling to have everything under control?






Now you can!


Our metrology solutions for all critical process steps enable you to:

- Ensure using the **best raw materials**
- Produce solar cells and modules with **consistent high quality**
- Lower cost and create **attractive pricing** for your customers
- Create **ultimate trust** in you product using comprehensive QC solutions




We provide dedicated metrology solutions for following processes:

- Inline SiNx Thickness and Refractive Index
- Stand-Alone SiNx Thickness and Refractive Index





- Inline Micro-crack
- Inline Wafer Reflectivity
- Inline Wafer Thickness
- Inline Dopant Weight



We provide dedicated metrology solutions for following processes:

- Inline & Stand-Alone String & Module EL before lamination
- Inline & Stand-Alone Module EL after lamination





OSIS Wafer

Inspection Items:

- Micro & macro cracks
- Inclusions & Holes
- Grain density & Geometry




Features and Capabilities:

- **High resolution** camera >> 4096 pixel / 40 μ m defect detection
- On-the-fly scan >> **No downstream interruptions** for measurement
- Transmission NIR setup >> **Bulk defect and crack detection**
- Full frame image >> Wafer inspected to the edge; no cropping
- Durable LED light source >> No consumables; low maintenance cost
- Full user access to images >> **Better defect cause analysis**


OSIS Wafer: Scan example





- Micro crack in pc-wafer




- Inclusion in pc-wafer



OSIS Wafer: Grain geometry and properties




- High grain density in pc-wafer



OSIS Texture

Inspection Items:

- **Wafer reflectivity**
- Reflectivity trend



Features and Capabilities:


- Inline measurement
 - each wafer is measured
 - On-the-fly scan
 - Wafer reflectance
 - Self-referencing
- >> *Significantly **less labor** than manual weighing*
 - >> ***Direct process feedback** (batch monitoring)*
 - >> *No downstream interruptions for measurement*
 - >> *Measure the target parameter directly*
 - >> *Accurate and long-term stable*


OSIS Texture



OSIS Texture

- Average reflectance per wafer
- Reflectance map of one wafer
- Reflectance trend of batch
- Small probe between tracks





OSIS Wafer Thickness


Inspection Items:


- Wafer Thickness

Features and Capabilities:

- Optical measurement
- Fast inline measurement
- For textured wafers
- Thickness measurement

- >> **Non-contact**, hence wafer is not touched
- >> No process bottle neck
- >> Measure the actual produced wafers directly
- >> **Direct measurement of etch removal rate**
(comparing before and after texturing)





OSIS Dopant

Inspection Items:


- H3PO4 Dopant Weight

Features and Capabilities:

- Optical measurement
- Fast inline measurement
- Weight trend

- >> *Non-contact, hence wafer is not touched*
- >> *Quick process feedback*
- >> ***No offline weighing needed***






OSIS Coating


Inspection Items:

- SiN thickness
- SiN refractive index
- **Coating distribution**




Features and Capabilities:

- Measure production wafers >> ***Directly on the textured mc- and pc-wafers***
- Fast **inline measurement** >> *20x20 points in less than 0.5s*
- Dense offline measurement >> *100x100 points in less than 15s*
- Very accurate >> *directly comparable to conventional methods*
- Inline version >> *direct process feedback, **faster ramp-up***




OSIS Coating Inline: Presentation example




- Inline
- Real-Time
- On Wafer
- Over Carrier






OSIS Coating Inline: Presentation example






- Inline
- Real-Time
- On Wafer
- Over Carrier






OSIS Coating: High-speed stand-alone system





OSIS Coating: High-speed stand-alone system

- Dense distribution maps
- Distribution profiles
- Touchscreen operation
- Reporting functions
- USB, LAN, WLAN



OSIS Cell

Inspection Items:

- Cracks
- Dislocations
- Dark areas
- Shunts



Features and Capabilities:

- Defect detection by software >> ***Fast and consistent sorting***
- Adjustable quality limits >> *Convenient sorting*
- **Flexible platform** >> *Automatic + sorter / automatic / manual*
- Make the invisible visible >> *Find and diagnose process errors*

OSIS Cell: System versions



■ Manual



■ Automatic

OSIS Cell: System versions



OSIS Cell: Cell Sorting

Highlights:

- 4 Input boxes
- 5 Sorting boxes/classes
- 1800 cells/hour
- automatic sorting
- gentle cell handling
- optional IV-tester
- optional AOI




OSIS Cell: Presentation example

Op-tection GmbH: OSIS Cell

File View Measure Setup Help

Image



Operate

Running

Inspection Result

Fail


Statistics

Inspected	8757
Pass	7969
Fail	788
Total Yield	91
Recent Yield	79

History

F	F	F	M	M	A	A	A	A	A
A	A	A	A	A	A	A	A	F	A
A	A	F	A	A	F	A	A	A	A
A	A	A	A	A	A	A	A	F	A

Defect Images



Setup Quality Management


Classes

Defect	Quality
High Crack Size	C
Low Crack Size	B
High Dark Area Size	D
Low Dark Area Size	C
Timeout Defects	Reject
Defect Overflow	Reject


- EL Image
- Results
- Defects
- Statistics

OK Cancel

OSIS Cell: Measurement example




■ mc-Cell with Crack & Shunt




■ pc-Cell with missing pn-Junction

OSIS Cell: Measurement example




■ Dark area (edge isolation)




■ Crack

OSIS String: Measurement example



- Defects in a string



OSIS Module


Inspection Items:

- Cracks
- Dislocations
- Dark areas
- Dead cells / strings




Features and Capabilities:

- Single or multiple cameras >> *Crisp **high-resolution** images*
- Flexible platform >> *For pre- and post-laminated module inspection*
- **Easy handling** >> *Module handling at practical working height*
- **Inline version** available >> *1m pass-line height sunny-side down inspection*



OSIS Module: Proven practicability







OSIS Module: Proven practicability




- Ergonomic system design for quick operation
- Practical module handling height
- Quick electrical connection using standard connector(s)
- High Resolution Images
- Fully automatic inline module inspection




OSIS Module-I: Inline Module Inspection




OSIS Module: pc-module measured with OSIS Module




- Overview image and high-res image




OSIS Module: CIGS panel measured with OSIS Module



- Small anomalies can be found




METROLOGY meets MES:
The Quantum Leap in PV Yield,
Efficiency and Quality



Combining OSIS Metrology tools with cmNavigo MES

Value for solar panel producers:

- Direct insight in correlation of process steps and parameters
- Excellent accessibility of production data
- 100% traceability from raw material to end-product
- Competitive advantage while ensuring product lifetime



Now, what can we do for you?



Content and specifications are subject to change without notice.
Third party brands and names are the property of their respective owners. Design by Winergetic www.winergetic.com

Op-tection GmbH
Borsigstrasse 80
52525 Heinsberg, Germany

T: +49 2452 967180 10
F: +49 2452 967180 40
E: office@op-tection.com

